Pyrolysis and gasification to provide a flexible pathway for advanced biofuel production

CONVERGE workshop

Evert Leijenhorst Petten, 18/5/2022 biomass technology group

Your partner in bioenergy

Introduction - Advanced biofuels through pyrolysis & gasification

- Decentralized fast pyrolysis of biomass for FPBO production (25 MW_{th} ~ 40 kt dry/y)
 - ✓ Scale matches with typical biomass availability, e.g. sawmill or palm-oil residues (EFB)
 - ✓ Convert heterogeneous solid biomass into an uniform liquid bioenergy carrier
 - ✓ Increase energy density (on volumetric basis primarily)
- Transport of FPBO from multiple plants to central gasifier (>100 MW_{th})
 - $\checkmark\,$ Gasifier benefits from economy of scale
 - ✓ Liquid fuel allows easy pressurization & pressurized operation of the gasifier
 - ✓ FPBO contains <5% of inorganic elements present in biomass</p>
 - > Avoiding ash melting problems & Potentially allowing the use of a dedicated catalyst

















Introduction: Fast Pyrolysis of Biomass – Technology Status

- Commercialization through sister company BTG Bioliquids BV.
- Currently 3 plants in operation, cumulative FPBO production close to 100.000 m³

Empyro – Hengelo (NL)

In operation since 2015 20 million litres FPBO/year ~25 MWth input FPBO used to replace natural gas in a steam boiler

GFN – Lieksa (FI)

In operation since 2020 24 kton FPBO/year

FPBO for heating applications

Pyrocell – Gävle (SE)

In operation since 2021 24 kton FPBO/year

FPBO used as co-feed in Preem refinery, biofuel production



biomass technology a





Introduction - Autothermal catalytic reforming

- Oxygen blown, steam for H_2/CO_2 and temperature control, pressurized operation
- FPBO contains much less contaminants than biomass use of catalyst feasible
- Lower operating temperature should increase energetic efficiency (compared to EF)



Materials & Methods - The autothermal catalytic reformer

Design, construction and commissioning of a 10 kW gasifier



Materials & Methods – atomization of FPBO

Pressurized atomization:

- Atomization based on kinetic energy diff.
- High liquid pressure 50-100 bar needed
- Fuel supply difficult to control, high capacity for proper atomization (3-4 kg/h)
- Ethanol required, 20 wt.% in FPBO
- FPBO₂₀ preheating to ~40 °C



Ultrasonic atomization:

- Atomization based on ultrasonic vibration
- Fuel supply pressure slightly above gasifier pressure
- Fuel supply easy to control, around 1 kg/h for proper operation
- No ethanol required! pure FPBO
- FPBO preheating to ~ 40 °C



Materials & Methods – Catalytic reforming

- Packed bed catalytic reforming zone
- Commercially available reforming catalyst
 - ReforMax 330
 - 10-hole spoked weel
 - Potassium-promoted nickel based on Al₂O₃
 - Applied in natural gas / nafta reforming
- Excess of catalyst (best case start):
 - GHSV ~ 900 h⁻¹ for pressurized atomization [m³/h syngas / m³ cat]
 - GHSV ~ 300 h⁻¹ for ultrasonic atomization system [m³/h syngas / m³ cat]





Materials & Methods – FPBO composition

Ultrasonic Fast pyrolysis bio-oil (FPBO) from various biomass materials: **Pine Wood** Arundo Wood **Biomass** Unit Eucalyptus Shorghum residue BTG **FPBO** Producer VTT VTT VTT GFN Ethanol added [wt.%] 20% 20% 20% 20% 0% Elemental composition (a.r.)^A Carbon [wt.%] 44.5 43.4 45.8 42.9 44.4 [wt.%] 8.9 Hydrogen 7.5 8.5 8.4 7.1 Nitrogen [wt.%] 0.3 0.4 0.3 0.7 0.3 Oxygen (diff) [wt.%] 47.7 47.3 45.4 48.0 48.2 [wt.%] 22.3 22.9 19.8 25.6 19.5 Water content LHV (a.r.)^B [M]/kg]16.8 18.0 18.7 17.1 16.3 Viscosity (40°C) [cSt] 16.2 6.8 11.7 7.5 40 MCRT [wt.%] 17 12.6 14.8 12.7 17.1

 A = Elemental composition measured including ethanol B = LHV calculated using the Milne correlation **btg**

Results and discussion – Pressurized atomization



100%

Dry syngas composition:



- ✓ Minor variation in gas composition for different FPBO's
- ✓ Carbon conversion 90-95%
- ✓ Dry syngas ~ 1.7 Nm³/kg FPBO

Operating conditions:

- Pressurized atomization
- Temperature ~ 900 °C
- Temp catalyst ~ 800 °C
- ER ~ 0.3
- S/C ~ 1.4
- 20 wt.% EtOH in FPBO



Results & Discussion - Deactivation of the catalyst

- Measurements with the pressurized atomisation & FPBO₂₀.
- Methane production (conversion) as indicator



- However, temperature drop shows deactivation
- More than only methane reforming, C2 C20⁺
- Tar analysis performed; reproducibility difficult for now



3. Results & Discussion – Ultrasonic atomization

Pure FPBO (GFN), triplicate test



Operating conditions:

- Ultrasonic atomization
- Temperature ~ 900 °C
- Temp catalyst ~ 800 °C
- ER ~ 0.38
- S/C ~ 1.3

- ✓ Very stable gas composition, no deactivation so far
- ✓ Carbon conversion ~ 95%
- ✓ Dry syngas ~ 1.7 Nm³/kg FPBO



Conclusion & Outlook

Experimental setup performs very well:

- ✓ Fuel flexible
- ✓ Reproducible tests, good balance closure
- ✓ Gas composition approaches thermodynamic equilibrium

Concept works:

- ✓ Synthesis gas composition <u>virtually independent of biomass feedstock</u>
- ✓ Use of FPBOs from different resources in same gasifier should be no problem

Future work:

- \rightarrow Atomization requires improvement: Carbon to Gas 90-95%, needs to go (close) to 100%
- ightarrow Pressurized gasification desired for subsequent syngas conversion processes
- ightarrow Catalytic activity requires detailed investigation
- ightarrow Overall chain evaluation; syngas composition & quality versus product choice





"This project has received funding from the European Union's Horizon 2020 research and innovation programme under grant agreement No 744821"



"This project has received funding from the Dutch Government, Topsector Energiesubsidie van het Ministerie van Economische Zaken contract No TEEB119005"



Contact

Visiting address Josink Esweg 34 7545 PN Enschede The Netherlands

+31 (0)53 486 1186 +31 (0)53 486 1180

Postal address

P.O. Box 835 7500 AV Enschede The Netherlands

www.btgworld.com office@btgworld.com



biomass technology group

btg

Your partner in bioenergy